



1. Hand tighten the sides where the halves touch first (Front, side with arrows pointing forward)
2. Torque gap side to 9 ft-lbs (Back)
3. Torque touching halves side to 9 ft-lbs
4. Check all bolts to ensure torqued to 9 ft-lbs

